

Assembly Instructions – 80L Pedal Bin (Kit 804)

Important: Perform all assembly steps with the bin placed upside down, so that the wheels are facing up.

Step 1 - Attach the Wheel and Axle Group

Hang the wheels and axle in position as shown in the diagram.

Step 2 - Install the Foot Pedal

Insert the foot pedal onto the wheel axle pins.

Step 3 - Insert the Pedal Rods

Insert the two metal rods into the pedal slots (holes).

Note: The orientation of the loops on the rods will affect how the lid opens — it can create two different lid

Step 4 - Connect the Rod Loops to the Lid

Hook the loops of the rods into the designated slots on the underside of the lid.

Push firmly until you hear a "CLACK!", indicating they are securely in place.